

SPECIFICATION SHEET**JFW MODEL 50BA-002-95****BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY**

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

Frequency Range	200-6000 MHz										
Configuration	Two individually controlled solid-state programmable attenuators										
Enclosure Type	Mini-benchtop										
Impedance	50 Ohms nominal										
Attenuation Range	0-95 dB in 1 dB steps										
Startup/Default States (configurable)	Maximum attenuation (see ATTEN STARTUP command) DHCP enabled (see NET command) 4 Ethernet users (see NET USERS command) Prompts off (see PROMPT command) Jog speed 5 (see JOG SPEED command)										
VSWR	2.0:1 maximum										
Attenuation Accuracy (guaranteed monotonic)	<table><tr><td>± 0.50 dB</td><td>1-3 dB</td></tr><tr><td>± 0.75 dB</td><td>4-7 dB</td></tr><tr><td>± 1.00 dB</td><td>8-11 dB</td></tr><tr><td>± 1.25 dB or 4%</td><td>12-95 dB</td></tr><tr><td colspan="2">(whichever is greater)</td></tr></table>	± 0.50 dB	1-3 dB	± 0.75 dB	4-7 dB	± 1.00 dB	8-11 dB	± 1.25 dB or 4%	12-95 dB	(whichever is greater)	
± 0.50 dB	1-3 dB										
± 0.75 dB	4-7 dB										
± 1.00 dB	8-11 dB										
± 1.25 dB or 4%	12-95 dB										
(whichever is greater)											
Insertion Loss	8.8 dB maximum 4.0 dB typical @ 200 MHz 4.5 dB typical @ 700 MHz 8.2 dB typical @ 6000 MHz										
RF Input Power	+27 dBm average +33 dBm (no damage)										
Switching Speed	4 microseconds typical (after command is received and processed) (3 milliseconds typical processing time)										
DC Supply	+12 Vdc (100-240 VAC AC/DC transformer included)										
Manual Control	Momentary Lever Actuator Switches with 7-Segment LED Displays (tap to step, hold to jog) (jog speed range is 0-10) (jog speed set to 0 will disable all levers)										
Remote Control	Ethernet (DHCP, TCP/IP, 10/100, up to 12 users) RS-232 (up to 115200 Baud)										

--CONTINUED--

SPECIFICATION SHEET**JFW MODEL 50BA-002-95****BENCHTOP PROGRAMMABLE ATTENUATOR ASSEMBLY**

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

Remote Commands

Attenuator Control Commands:

Atten, Set Attenuator, Read Attenuator, Set All
Attenuators, Read All Attenuators, Read All
Extended, Fade Attenuator, Variable Attenuator
Handover, Block, Set Block, Read Block, Read All
Blocks, Fade Block, Variable Block Handover

System Commands:

Help, Identification, Store, Recall, Pause, Net,
Serial, Close, Disconnect, MOTD, Date, Message,
Restrict, IDENT, Name, Show Users, Reboot, Uptime,
Prompt, Jog Speed

RF Connector

SMA female or N female

Operating Temperature Range

0°C to +50°C

Outline Drawing Numbers

092-6616 (SMA female)
092-8847 (N female)



ECR/ECN #	DATE	REV	APPR / DATE	ECR/ECN #	DATE	REV	APPR / DATE
18975	08/06/2010	A	CLK 08/06/2010	27975	06/14/2017	D	TRS 06/14/2017
20299	07/08/2011	B	CLK 07/08/2011	28159	10/05/2017	E	CLK 10/05/2017
24239	12/01/2014	C	TRS 12/01/2014	28495	02/09/2018	F	TRS 02/09/2018