

20W 18-26.5GHz Solid State Broadband - EMC Benchtop Power Amplifier



<u>Features</u>

- · High Saturated Power 43dBm.
- Microwave Radio and VSAT.
- · Aerospace and Military Applications.
- Telecom Infrastructure Applications.
- · High peak to average handling capability.
- · High linearity and low noise figure.
- Convenient AC Power Input.
- Integrated Heat Sink and Fan.
- All specifications can be modified upon request.

Electrical Specifications, $T_A=25$ °C Voltage = 110v/220v AC

Parameter	Min	Тур	Max	Min	Тур	Max	Units
Frequency Range	18		26.5		GHz		
Gain		43			43		dB
Gain Flatness		±1			±1		dB
Gain Adjustment Step (20dB Range)		0.1			0.1		dB
Noise Figure		6.5			7		dB
Input Return Loss		15			15		dB
Output Return Loss		25			25		dB
Output Power for 1 dB Compression (P1dB)							dBm
Saturated Output Power (Psat)		43			43		dBm
2 nd Harmonics		10			10		dBm
Spurious compression		40			40		dBc
Maximum Input Power (no damage)		Psat- Gain			Psat- Gain		dBm
Weight	50 lbs						
Impedance	50 Ohms						
Input / Output Connectors	N-Female						
Finishing	White Painted Finish						
Material	Aluminum / Copper						

RF-LAMBDA INC. www.rflambda.com



Absolute Maximum Ratings				
7 ibsolute maximum natings				
Supply Voltage	110v 220v AC 1.1A			
RF Input Power (RFIN)	` ' Pcat = (.ain			
Pin_max = Psat - Gainsat				
Storage Temperature (°C)	-50 to +125			

Note: Maximum RF input power is set to assure safety of amplifier. Input power may be increased at own risk to achieve full power of amplifier. Please reference gain and power curves.

Note: The operating temperature for the unit is specified at the package base. It is the user's responsibility to ensure the part is in an environment capable of maintaining the temperature within the specified limits

	Ordering Information				
Part No.		Description			
	RAMP18G26GJ	18-26.5GHz Power Amplifier			

Biasing Up Procedure				
Step 1	Connect input and output with 50 Ohm source/load. (in band VSWR<1.9:1 or >10dB return loss)			
Step 2	Turn on AC power.			
Step 3	Enable RF output			
-	Power OFF Procedure			
Step 1	Turn off RF output power			
Step 2	Turn Off DC power			
Step 3	Disconnect input and output			

Amplifier Use

Ensure that the amplifier input and output ports are safely terminated into a proper 50 ohm load before turning on the power. Never operate the amplifier without a load. A proper 50 ohm load is defined as a load with impedance less than 1.9:1 or return loss larger than 10dB relative to 50 Ohm within the specified operating band width.

Power Supply Requirements

Power supply must be able to provide adequate current for the amplifier. Power supply should be able to provide 1.5 times the typical current or 1.2 times the maximum current (whichever is greater).

In most cases, RF - Lambda amplifiers will withstand severe mismatches without damage. However, operation with poor loads is discouraged. If prolonged operation with poor or unknown loads is expected, an external device such as an isolator or circulator should be used to protect the amplifier.

Ensure that the power is off when connecting or disconnecting the input or output of the amp.

Prevent overdriving the amplifier. Do not exceed the recommended input power level.

Adequate heat-sinking required for RF amplifier modules. Please inquire.

Amplifiers do not contain Thermal protection, Reverse DC polarity or Over voltage protection with the exception of a few models. Please inquire.

Proper electrostatic discharge (ESD) precautions are recommended to avoid performance degradation or loss of functionality.

What is not covered with warranty?

Each RF - Lambda amplifier will go through power and temperature stress testing.

Since the die, ICs or MMICs are fragile, these are not covered by warranty. Any damage to these will NOT be free to repair.

RF-LAMBDA INC. www.rflambda.com

Rev(A2)10-17-2017 Sales: sales@rflambda.com Technical: support@rflambda.com