

SPECIFICATION SHEET
JFW MODEL 50PMA-106
TRANSCEIVER TEST SYSTEM

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

| | |
|--|--|
| Frequency Range | 2-6 GHz |
| Configuration | 4 Port Transceiver Test System (see block diagram 092-6984 for attenuator addressing) (all ports are bi-directional) (full fan-out i.e. every path has its own attenuator) (the ADMIN password is located on rear panel) |
| Enclosure Type | 19" rack mount @ 2RU high |
| Impedance | 50 Ohms nominal |
| Attenuation Range | 0-95 dB in 1 dB steps |
| Startup/Default States (configurable) | Attenuators to 95dB at startup (see ATTEN command) DHCP enabled (see NET command) 4 Ethernet users (see NET command) Prompts off (see PROMPT command) All of these default settings can be changed by user. Unit can be configured for up to 12 Ethernet users. |
| VSWR | 1.7:1 maximum 1.5:1 typical |
| Attenuation Accuracy | ± 0.7 dB 1-7 dB ± 1.0 dB 8-11 dB ± 1.25 dB or 4% 12-95 dB (whichever is greater) (guaranteed monotonic) |
| Insertion Loss | 29 dB maximum 23 dB typical @ 2 GHz 27 dB typical @ 6 GHz |
| Power Divider Isolation | 20 dB minimum 23 dB typical |
| RF Input Power | 1 Watt average |
| Switching Speed | 4 microseconds (after command received and processed) (3 milliseconds typical processing time) |
| Manual Control | 20-Button Keypad and LCD display (IP Address configurable via keypad) (Net mask configurable via keypad) (Gateway configurable via keypad) (Baud rate configurable via keypad) |

--CONTINUED--

SPECIFICATION SHEET
JFW MODEL 50PMA-106
TRANSCEIVER TEST SYSTEM

JFW Industries, Inc.
Phone: 317-887-1340
sales@jfwindustries.com
www.jfwindustries.com

Remote Commands Attenuator Control Commands:
Atten, Set Path, Read Path, Read All Paths, Set Attenuator, Read Attenuator, Set All Attenuators, Read All Attenuators, Read All Extended, Fade Attenuator, Variable Attenuator Handover, Block, Set Block, Read Block, Read All Blocks, Fade Block, Variable Block Handover, Set 2nd 32dB Bit

System Commands:
Help, Identification, Store, Recall, Pause, Net,
Serial, Close, Disconnect, MOTD, Date, Message,
Restrict, IDENT, Name, Show Users, Reboot, Uptime,
Prompt

RF Connector SMA female

AC Supply 100-240 VAC @ 47-63 Hz
2 Amp 5x20mm "Slo-Blo" AC fuse
Littelfuse #215-002, JFW #025-021

Operating Temperature Range 0°C to +50°C

Physical Size See outline drawing 092-8207

| ECR/ECN # | DATE | REV | APPR / DATE | ECR/ECN # | DATE | REV | APPR / DATE |
|-----------|------------|------|----------------|-----------|------|-----|-------------|
| 28159 | 12/15/2015 | TRSA | 12/15/2015 | | | | |
| | 10/05/2017 | A | CLK 10/05/2017 | | | | |